



### OPEN LOOP DC DRIVE FOR POSTIONING

(INPUT SOURCE MAY BE MANUALLY ADJUSTED POTENTIOMETER, OPAMP OUTPUT, OR D/A CONVERTER OUTPUT.)